



CT-6B Classic Blade Trim With Ivy

Tools Required

Permanent Marker
Drill Template (Included)
Hammer
Center Punch
3/8" Drill Bit
3/4" Wrench

Hardware Required

(2) 5/16-18 stainless hex-bolts
Classic Blade Trim With Ivy

Marking and Drilling Post

- 1) Locate sign height on installed post.
- 2) Use the included drill template to mark drill locations for 2 mounting holes.
- 3) Mark the opposite side of post at the same height (it is recommended to drill each side of post separately to ensure the holes line up properly through the fluted post).
- 4) Center punch each of 4 hole locations.
- 5) Drill 4 holes, 2 on each side of post, creating 2 through holes with a 3/8" drill bit.
- 6) Attach Classic Blade Trim to post using (2) 5/16-18 hex bolts.
- 7) Tighten bolts until trim is snug to post.
- 8) Repeat this process when installing a 2nd blade trims to the same post. Remember that the second sign must be located at a different height so that the bolts do not interfere with each other.